

For further assistance,  
please call us on  
03330 146 466

# Gas Pipe Excavation

In most cases it is the developers' responsibility to pre-excavate all trenches on site. This must be done before Fulcrum arrives on site, reference to Health and Safety Executive guidance will help ensure that this is done safely.

[www.fulcrum.co.uk](http://www.fulcrum.co.uk)

Table 1. Minimum Depth Of Cover

Service Pipe Cover		Mains Pipe Cover	
Private/garden	375mm	Public/footway	600mm
Public/footway	450mm	Roadway/verges	750mm
Public/roadway	450mm	Fields	1100mm

Figure 1. Typical Trench Layout



